


Thank you for choosing the Sanus Systems LAS1A. The LAS1A is designed to mount speakers on each side of a large VisionMount full motion TV mount. The LAS1A will support speakers weighing up to 11 kg (25 lbs.) each.

Do not use this product for any purpose not explicitly specified by Sanus Systems. Improper installation may cause property damage or personal injury. If you do not understand these directions, or have doubts about the safety of the installation, contact Sanus Systems Customer Service or call a qualified contractor. Sanus Systems is not liable for damage or injury caused by incorrect mounting, assembly, or use.


WARNING -

This product contains small items that could be a choking hazard if swallowed. Keep these items away from young children!



Supplied Parts and Hardware

Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the item to your dealer; contact Sanus Systems Customer Service. Never use damaged parts!




1: Preparation

1-1:New Installations


If you have purchased a Sanus Systems large VisionMount™ Full Motion Mount, but have not installed it, begin by following the large VisionMount™ Full Motion Mount instructions. Replace Cross Tube Installation with Step 2: Cross Tube Installation of the LAS1A instructions. When completed, refer back to this Instruction manual, starting at Step 3: Install Extension Tubes.

1-2: Existing Installations






HEAVY! You will need assistance with this step.




Using an Allen Key, loosen the six vise assemblies [D]. Remove the lower cross tube [E]; then, remove the upper cross tube [F] as shown.



2: Cross Tube Installation



Slide the cross tubes [**02**] into the first monitor bracket [**G**], through the arm assembly [**H**] and then through the second monitor bracket [**J**]. Center the cross tubes on the back of the TV. Using the Allen Key, tighten the six vise assemblies until the cross tubes no longer rotate.




Attach the TV and arm assembly to the wall plate according to the instructions provided with the large VisionMount[™] Full Motion Mount.



HEAVY! You will need assistance with this step.

– NOTE –

If you no longer have your VisionMount[™] Installation Manual, download one from www.Sanus.com or call Sanus Systems Customer Service.



3: Install Extension Tubes

Slide the four extension tubes [03] (felt end first) into the cross tubes [02].

[03]


[03]

4: Install Threaded Tube Clamp & Clamp Knob


Slide the threaded tube clamps **[05]** onto the extension tubes **[03]**, aligning the notches in the threaded tube clamp and cross tubes **[02]**.

Snap the threaded tube clamps onto the cross tubes.

Thread a clamp knob **[04]** onto each threaded tube clamp **[05]**. Do not tighten at this time.



5: Secure Vise Assemblies to Brackets




6: Attach Speaker Brackets



Slide the speaker brackets [**01**] into the extension tubes [**03**]. Use the Allen key to tighten the four vise assemblies [**04**] until the speaker brackets do not slide on the extension tubes.


NOTE -

Maximum extension of the cross tubes is 145cm (57 in.). Do not exceed the maximum extension.




7: Attach Speakers

7 - 1: Attach Speakers Using Threaded Fasteners



Disconnect the speaker wire from the receiver or amplifier when you route it through the upper or lower extension tubes **[03]** to avoid damage to the speakers, amplifier, or receiver.

7 - 2: Attach Speakers Using Hex Studs



CSAV, Inc. and its affiliated corporations and subsidiaries (collectively, "CSAV"), intend to make this manual accurate and complete. However, CSAV makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. CSAV makes no representation of warranty, expressed or implied, regarding the information contained herein. CSAV assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.